



# HOW TO USE AND CARE FOR YOUR NEW MAGNETIC VEHICLE SIGNS

**The vehicle surface and the brown magnetic side of the sign should be clean, dry and waxed prior to applying.**

## INSTALLATION

Contact one edge of the sign to the vehicle surface in desired location and then let the adjacent part of the sign contact the vehicle surface until the entire sign is held magnetically to the vehicle. Remove sign and straighten as needed. (Do not try to straighten sign by pulling when it is held magnetically to the vehicle. It may result in damage to the sign and/or vehicle.) Avoid placing your sign over chrome trim or surface irregularities of any kind. The temperature of the sign should be at least 60 degrees F. during installation. Avoid installation in extreme cold or hot.

## REMOVAL

**Never start at the corners** to remove a sign. Always remove the sign by lifting from the center of the two opposite sides. This precaution will avoid bent corners and reduced adhesion.

## CAUTION

Magnetic signs will not adhere to areas on your car where plastic or lead body fillers have been used. Use caution in applying vehicle signs to areas of your car that have been damaged and repaired in order to avoid losing your signs. Wait at least 60 days before positioning a sign on fresh paint.

## MAINTENANCE

Your signs should be periodically removed, wiped clean of debris and moisture, and reapplied. **James Allen Printing and the manufacturer of the magnetic material strongly recommend daily peel away removal of your signs.** Daily peel away helps to prevent the magnetic bond between the magnetic sheet and your vehicle from increasing and the sheet from becoming locked tight to the vehicle surface. **If left on your vehicle, the sign(s) could bond/weld to the vehicle metal and become very difficult to remove!!** Wipe dry both the vehicle and the back of the sign. Trapped moisture, dirt or chemicals may harm your vehicle finish. Clean your sign with plain water and a mild detergent.

## STORAGE

To avoid cracking or breaking, do not fold or crease. Store your magnetic sign flat.

## CLEANING

Use soft cloth dampened with water or mild dish detergent/water solution. **DO NOT** use any type of solvents / harsh household cleansers to clean sign. Inks used are solvent based and these type of cleansers could damage sign.

## WARRANTY

Your magnetic signs are warranted to be free from material defect or defect in workmanship for a period of 1 year. Warranty does not include, loss, abuse, etc. Improper installation and maintenance will void warranty.

I have read and understand the instructions stated above.

Customer Signature

Date